


### Charge Powerbank



Choose left or right USB-C port



### Saver Powerbank 27000

Item no. 320-43

[www.sandberg.world](http://www.sandberg.world)

[info@sandberg.world](mailto:info@sandberg.world)

Sandberg A/S

Bregnerodvej 133D,


3460 Birkerød, Denmark

Made in China



**NOTE:** For optimal battery performance, we recommend fully discharging and recharging the powerbank at least once every three months.

## Charge devices



## Example of use