

Survivor Radio All-in-1 5000

Quick guide










Product overview




- 1. Power / Mode switching 2. Lights
- 3. SOS
- 5. Display
- 4. Volume -

- 6. Skip station / song <
- 7. Search/Select/Pause
- 8. Solar panel
- 9. Retractable antenna 10. Skip station / song >
- 11. Hand crank
- 12. Volume +
- 13. Light switching
- 14. Charging / Headphone
- 15. Speaker



Display overview



- Information display (Numbers or text 4 digits)
- Bluetooth speaker mode
- WR weather alert on
- Wb weather a
 Battery status
- 5. Frequency KHz / MHz
- 6. Charge indicator
- 7. Radio mode FM / AM / WB

Charging the internal battery

Hand crank



- Turn the crank at 120 - 150 rpm (2 - 2.5 times per second). 1 minute of turning can power the radio for about 3 minutes.
- Approximately charging time by the hand crank (battery 0-25%): 5 hours

Solar panel




- Make sure to place the solar panel in direct sunlight with no shadow.
- Approximately charging time by the solar panel (battery 0-25%): 20 hours

AC charger





Charge device



Operation

Symbol	Press	Function
%/M	Long (3 sec)	Power on/off



Symbol	Press	Function	Options
U/M	Short (toggle)	Select mode	FM
۵/M	Short (toggle)	Select mode	AM
@/M	Short (toggle)	Select mode	WB
@/M	Short (toggle)	Select mode	Bluetooth

WB (Weather Broadcast NOAA) Mode: This service is only available in US and some other countries.

Symbol	Press	Function	Options
\ll \gg	Short (toggle)	Select songs forward / backwards	Skip-next/previous
Q/NI	Short (toggle)	Pause/Play	-

Symbol	Press	Function	Options
\ll \gg	Short	Frequency up / down	Manual setting
\ll \gg	Long	Frequency up / down	Auto search
Q/NI	Long	Full auto search and storage	P01-P99
Q/NI	Short (toggle)	Select prestored channels	P01-P99

Symbol	Press	Function	Options
\ll \gg	Short (toggle)	Select prestored channels	CH1 - CH7
Q/NI	Long	Auto NOAA Alert ON	Go to next step
Ů/M	Short	Exit Auto Alert state	

Speaker volume setting

Symbol	Press	Function	Options
_	Short (repeating)	Volume down	Steps 0-27
4	Short (repeating)	Volume up	Steps 0-27



SOS alarm (Warning! Loud horn sound and red light)

Symbol	Press	Function	Options
SOS	Short (first time)	Activate SOS alarm horn & light	-
SOS	Short (second time)	Deactivate SOS alarm horn & light	-

LED light


Symbol	Press	Function	Options
8	Short (toggle)	Turn on/off center torch	Long beam
8	Long (toggle)	Turn on/off side torches	Short beam

Bluetooth Mode

When no device is connected, it will be visible for your Bluetooth search.



Turn on Bluetooth on your mobile phone or tablet or computer.



Look for "421-03" in your Bluetooth search list and select connect.



CE letter of conformity

Declaration of Conformity

Manufacturer: Sandberg A/S

Address: Bregneroedvej 133D, 3460 Birkeroed, Denmark

Product description: Multi device of powerbank, AM+FM radio, speaker and

Survivor Radio All-in-1 5000 / 421-03

We declare under our sole responsibility that the products, to which this declaration relates, are in conformity with the Council Directives on the approximation of the laws of the EEC Member States relating to the following:

lamp

Directives

EMC Directive 2014/30/EU

Product name/Type no:

RED Directive 2014/53/EU

RoHS Directive 2011/65/EU with amendment (EU)2015/863:

And standards

EN IEC 62368-1:2020+A11:2020

FN 62479:2010

ETSI EN 301 489-1 V2.2.3 (2019-11)

EN 301 489-17 V3.2.4 (2020-09)

217 302 103 27 73.2.7 (2020 0

ETSI EN 303 345-1 V1.1.1:2019

ETSI EN 303 345-2 V1.2.1:2021

ETSI EN 303 345-3 V1.1.1:2021

Date: 15th June 2024

Location: Birkeroed, Denmark

Name: Anders Petersen

7





http://helpdesk.sandberg.world

Warranty

There is a five-year warranty on your Sandberg product.

Please read the warranty terms and register your new
Sandberg product at www.sandberg.world/warranty

Years Warranty

Survivor Radio All-in-1 5000

---it-- 5000 -- Ab (10 5 Wb)

Solar Panel Voltage: 5V, 95 mA (0.48W max)
Hand crank power: 5V, 380 mA (1.9W max)
USB-A output: 5V/2A USB-C input: 5V/1.5A

Padio FM: 97.0 100.0 MUz

Radio FM: 87.0 - 108.0 MHz

tom no. 421.02

www.sandberg.world

Sandberg A/S Bregneroedvej 133D, 3460 Birkeroed, Denma



NOTE: For optimal battery

performance, we recommend fully discharging and recharging the power bank at least once every three months

